



## RFID-reader ADM20

Operation manual

edition 1.1

EAC

This Operation Manual relates to the compound receiver-transmitter ADM20 (hereinafter referred as RFID-reader, reader) and defines installation and connection procedure, as well as describes the device function.

The Operation Manual is designed for professionals familiarized with the rules of repair and installation works execution related to vehicles and having special knowledge in electronics and electrical equipment of various vehicles.

To ensure proper function, the reader's installation and setting should be performed by qualified professionals. To properly use the equipment, it is necessary to familiarize with the monitoring system operation principles and understand the function of all its particular components.

# Table of Contents

<b>1. Application and Operation principles</b> .....	<b>3</b>
<b>2. Technical Features</b> .....	<b>4</b>
<b>3. System design and operation based on RFID-reader ADM20</b> .....	<b>4</b>
<b>4. Installation and setting procedure</b> .....	<b>5</b>
<b>4.1 RFID-reader ADM21 installation</b> .....	<b>5</b>
<b>4.2 RFID-reader ADM20 contacts assignment</b> .....	<b>5</b>
<b>4.3 RFID-reader ADM20 setting</b> .....	<b>5</b>
<b>5. Using the RFID-reader ADM20 together with the ADM100/ADM300/ADM700 trackers</b> .....	<b>6</b>
<b>5.1 Operation modes description</b> .....	<b>6</b>
<b>5.1.1 Mode 0: “RFID card periodic check”</b> .....	<b>6</b>
<b>5.1.2 Mode 1: “Guaranteed RFID-card sending”</b> .....	<b>6</b>
<b>5.1.3. Mode 2: “Radiotags ADM21”</b> .....	<b>7</b>
<b>5.2 Operation mode setting</b> .....	<b>7</b>
<b>5.3 Operation mode setting</b> .....	<b>7</b>
<b>5.3.1 Installation of the terminal's discrete output when detecting the card</b> .....	<b>8</b>
<b>5.4 Examples of setting with commands</b> .....	<b>8</b>
<b>5.4.1 Step by step setting with comments</b> .....	<b>8</b>
<b>5.4.2 Examples for quick setting</b> .....	<b>9</b>
<b>6. Using the RFID-reader ADM20 together with trackers of other manufacturers</b> .....	<b>9</b>
<b>7 Reader's software upgrade</b> .....	<b>10</b>
<b>7.1 Reader's software upgrade with the firmware file</b> .....	<b>10</b>
<b>8. Storage and transportation requirements</b> .....	<b>11</b>
<b>9. Warranty</b> .....	<b>11</b>
<b>10. Marking and packaging</b> .....	<b>11</b>
<b>11. Disposal</b> .....	<b>12</b>
<b>12. Scope of supply</b> .....	<b>12</b>

# 1. Application and Operation principles

RFID-reader ADM20 (see the picture 1) is used for installation on moving and stationary objects and identification of objects by means of radiosignals as well as attendance recording. It might be used within close and remote identification subsystems.

Close identification subsystem allows to the RFID-reader to accept data from cards and keychains (Mifare, Em Marin) at the distance of 1-5 cm. Remote identification subsystem allows to accept data from autonomous tags ADM21 (see the picture 2) at the distance up to 100 m.

In this way, the Radio Frequency Identification system for objects based on the RFID-reader ADM20 might be used for fixing issues related to staff's and extra equipment identification, attendance recording, towed vehicles control, materials write-off, engine start management, vehicles identification on weighing units, arranging an authorized passage of vehicles within companies' facilities, recording vehicles'attendance to checkpoints, handling passanger and freight carrages, etc.

The Radio Frequency Identification system might be used both within a monitoring unit or independently. When using the system within a monitoring unit, the data received from the tags and cards are transmitted to the subscriber's telematic terminal via RS-485 interface.



Picture 1. ADM20 general view



Picture 2. ADM21 tag general view

## 2. Technical Features

- Supply voltage: +9..+40 V of unregulated direct current
- RS-485 Interface: 1.
- Radio channel frequency for remote identification: 868 MHz
- Radio channel frequencies for close identification: 125 kHz, 13,56 MHz.
- Working with Mifare, Em Marin cards.
- Simultaneous work in all ranges.
- «Open collector» output quantity: 1
- Discrete inputs quantity: 1.
- Firmware upgrade
- Sound and light indication
- Operation temperature: -40..+85°C.
- IP case
- Case material: ABS plastic
- Dimensions: 82x130x26 mm.
- Weight: at most 250 g

## 3. System design and operation based on RFID-reader


### ADM20

During its work the telematic terminal interrogates the RFID-reader ADM20. If there are active tags ADM21 within its range, the reader transmits their identification numbers to the terminal. At the same time, RFID-cards applicated to the reader are being read in the range of 13,56 MHz and 125 kHz. Then the telematic terminal uploads data onto telematic server.

## 4. Installation and setting procedure

### 4.1 RFID-reader ADM21 installation

RFID-reader ADM20 is mounted on an object with two screws with a pressure-pad of diameter 4.2 mm and length of at least 25 mm. For fixation it is necessary to remove the reader's hopper 1 (see the picture 3), tighten the screws in the holes 2 (see the picture 3), put the hopper in its place again. No need to dismantle the reader's case.



Picture 3. RFID-reader ADM20 installation

### 4.2 RFID-reader ADM20 contacts assignment

Table 1. RFID-reader ADM20 contacts assignment

Color	Assignment
Pink	+ Vehicle network
Grey	GND (Ground)
Yellow	RS-485 A
Green	RS-485 V
White	Discrete output
Brown	Discrete input

### 4.3 RFID-reader ADM20 setting

Connect RFID-reader ADM20 to the computer with the convertor RS-485/USB. During setting only one reader ADM20 should be connected on the RS-485 bus.

Install and launch the “RFID Configuration” program (might be downloaded from the web-site <http://neomatica.ru>).

After detecting ADM20, the program will display its serial number, firmware version and address. The configurator allows changing the reader's network address and three subnets, which will be questioned by the reader when searching for ADM21 tags. If all three subnets are installed as “0”, the reader will accept data from all subnets tags.

## **5. Using the RFID-reader ADM20 together with the ADM100/ADM300/ADM700 trackers**

Connect the reader ADM20 to the terminal's RS-485 bus. Reader-telematic terminal coordination is performed on the terminal's side by sending respective commands or in AdmConfigurator's graphical interface whose version is not below 2.1.

### **5.1 Operation modes description**

The RFID-reader ADM20 might be set for working in the following modes: Mode 0 - “RFID card periodic check”, Mode 1 - “Guaranteed RFID card sending” and Mode 2 - “Radiotags ADM21”.

#### **5.1.1 Mode 0: “RFID card periodic check”**

When setting this mode, the terminal is questioning regularly (every 10 sec) the RFID-reader. The card number is transmitted in an ordinary packet if available at the moment of the last interrogation performed by the reader.

Parameters set for this mode:

- number of the analogue input whose data will be replaced by the card number,
- number of the terminal output, which will change its state when detecting the card.

#### **5.1.2 Mode 1: “Guaranteed RFID-card sending”**

In this mode devices work according to the following algorithm. When detecting a card by the RFID-reader, the card is recorded in its memory. The card number remains in the RFID-reader memory until the data are received by the terminal, and then it is removed. The terminal questions the RFID-reader with the pre-set frequency (every 5 sec by default), and if it detects the card number in its memory, an extraordinary sending with the card number is formed for the server.

Parameters set for this mode:

- terminal's interrogation frequency by the reader,
- number of the analogue input whose data will be replaced by the card number,
- output number of the terminal, which will change its state when detecting the card.

### 5.1.3. Mode 2: “Radiotags ADM21”

In this mode when RFID-reader detects ADM21 tags, the tag is recorded in its memory, and after receiving data by the terminal, it is removed.

Parameters set for this mode:

- number of the analogue input whose data will be replaced by the tags numbers.

This mode might be used together with the modes 0 or 1.

## 5.2 Operation mode setting

The reader number and necessary operation modes are installed with the «ADM20 X,Y,Z» command.

X – installs the reader's number. Values from 0 to 4 are possible. The maximum quantity of readers connected to one terminal, might be 5 pieces.

Y – the reader's address on the RS-485 bus. The real address for the reader should be indicated.

Z – installs active operation modes. Select the convenient Z-parameter value according to the table and operation modes description.

Table 2. Z-parameters compliance with operation modes

Z-parameter values	Operation modes
1	0
2	1
5	0 and 2
6	1 and 2
4	2

## 5.3 Operation mode setting

Extra parameters are installed with the «ADM20MODE» command: parameter Y – for the selected operation mode, parameter X – for the indicated reader. When it is necessary to set several operation modes or RFID-readers ADM20, send the command as many times as needed indicating the reader's number and mode, which should be set.

ADM20MODE X,Y,Z,A,B

X – number of the reader set (installed by the command ADM20).

Y – number of the mode set (might be seen in the section 5.1 “Operation modes description”).

Z – card check frequency (is set only for the mode 1).

A – number of the analogue input whose data will be replaced by the card number.



B – discrete output number. The selected discrete output of the terminal is connected to the ground when the card is not available, and when the card is detected, it is not linked to anything (not settable for the mode 2).

In case if in the selected mode a parameter cannot be set, its value should be, however, indicated when entering the command (it will be disregarded). It is permissible to write any arbitrary figure, for example, “1”. In response to the command, these values will be replaced by «n/a».

To transmit the card number, it is necessary to enable “Analogue inputs” data block transmission.

### **5.3.1 Installation of the terminal's discrete output when detecting the card**

The terminal's discrete output state when there is no card in the reader ADM20 as well as its state when the card is detected, are installed by the «ADM20OUTMODE» command.

ADM20OUTMODE X,Y

X – reader's number

Y – output state when detecting the card

Y=0 - when there's no card, the output is connected to the ground, when the card is detected, the output is deactivated.

X=1 - when there is no card, the output is deactivated, when there is the card, the output is connected to the ground.

## **5.4 Examples of setting with commands**

### **5.4.1 Step by step setting with comments**

1) ADM20 1,3,6

Answer: ADM20[1] 3,6 ready

The reader with address 3 is connected, the number 1 is attributed to it and the following modes are activated: “Guaranteed RFID-card sending” and “Radiotags ADM21”.

2) ADM20MODE 1,1,5,3,0

Answer: ADM20MODE[1] 1,5,3,0 enabled

For the reader # 1, for the mode “Guaranteed RFID-card sending” the following is set: interrogation frequency 5 seconds, card number transmission instead of AIN3 data, terminal's OUT0 output state change when detecting the card.

3) ADM20MODE 1,2,1,4,1

Answer: ADM20MODE[1] 2,n/a,4,n/a enabled

For the reader # 1, for the mode “Radiotags ADM21” the following is set: tags numbers transmission instead of AIN4 data.

4) PROTOCOL 8

“Analogue inputs” data block transmission enabled.

#### **5.4.2 Examples for quick setting**

1) Card number transmission is made with the common frequency instead of AIN5 data. When detecting the card, the terminal's output “0” (OUT0) will change its state.

It is fit for situations when the card will be applied for long time, for example, during a trip. It might not work out when the card is applied for short time.

ADM20 0,0,1

ADM20MODE 0,0,1,5,0

2) Card number transmission is made in an extraordinary packet instead of AIN5 data. The number is stored until it is sent. When detecting the card, the terminal's output “0” (OUT0) will change its state.

It is fit for situations when the card will be applied for a while.

ADM20 0,0,2

ADM20MODE 0,1,5,5,0

3) The detected tags numbers are stored in the memory until they are sent. Transmission is based on AIN4 analogue input data replacement.

ADM20 0,0,4

ADM20MODE 0,2,1,4,1

4) Card number transmission is made in an extraordinary packet instead of AIN5 data. The number is stored until it is sent. When detecting the card, the terminal's output “0” (OUT0) will change its state. The detected tags numbers are transmitted instead of AIN4 data. When detecting the tag, its number will be stored in the memory until its sending.

ADM20 0,0,6

ADM20MODE 0,1,5,5,0

ADM20MODE 0,2,1,4,1

## **6. Using the RFID-reader ADM20 together with trackers of other manufacturers**

ADM20 may be utilized as a periphery device with other GPS trackers. To be compatible with ADM20, a tracker should be equipped with RS-485 digital interface and support LLS exchange protocol. Thus, the reader will be counted as a fuel level sensors and should be configured with a respective network address for the correct functioning of request - response logic. In this case, it will be possible to receive ADM21 RFID-tag information, that will occupy one of the “fuel level” fields.

The data of RFID-cards may be transferred only in case of full integration of the tracker and the reader have been conducted.

## 7 Reader's software upgrade

Reader's software upgrade (firmware) might be performed via RS-485 interface by means of Configurator program.

The Configurator program checks the relevant firmware version in the upgrade server if there is access to the Internet, and when necessary, downloads the firmware file.

To upgrade firmware do the following:

- after having switched off the external power, connect the reader to the Personal computer's via the interface converter RS-485\USB.
- supply the power to the reader from the vehicle network or a laboratory power source;
- launch the “RFIDConfigurator” program on personal computer;
- in the “ADM20 Setting” section the “RFID Configurator” program will display the new software version;
- if this new version is newer than the one installed on the reader, press the button “Upgrade”;
- in the opened window “ADM20 reader software upgrade”, press “Upgrade” (Upgrade from the server);

Upgrade process is considered as finished after the line “the File has been flashed fully” appears.

**WARNING!** Don't switch the terminal's power off when upgrading the terminal's firmware until the terminal is detected by the setting program. Otherwise there is a risk of damaging the software whose recovery can be performed only in the manufacturer's office.

### 7.1 Reader's software upgrade with the firmware file

**It is necessary to request the firmware file in the technical support.**

To upgrade the firmware do the following:

- after having switched off the external power, connect the reader to the Personal computer's via the interface converter RS-485\USB.
- supply the power to the reader from the vehicle network or a laboratory power source;
- launch the “RFIDConfigurator” program on personal computer;
- open the section “ADM20 setting”;
- press the button “Upgrade”
- in the opened window “ADM20 reader software upgrade”, press “...” (Upgrade from the file), select the firmware file;

- press “Upgrade” (upgrade from the file).

Upgrade process is considered as finished after the line “the File has been flashed fully” appears.

**WARNING!** Don't switch the terminal's power off when upgrading the terminal's firmware until the terminal is detected by the setting program. Otherwise there is a risk of damaging the software whose recovery can be performed only in the manufacturer's office.

## **8. Storage and transportation requirements**

Equipment should be stored in a warehouse at a temperature of +5°C to +40°C and relative humidity at most 85 %.

After terminals' transportation in sub-zero temperatures they should be stored at room temperature within 24 hours.

## **9. Warranty**

The manufacturer guarantees the RFID-reader proper function within 12 months from the day of its sale if consumer meets all the requirements and follows all the rules of transportation, storage, installation and handling.

The warranty does not cover:

- a device with mechanical damages and defects (cracks and chips, dents, signs of impacts, etc.) caused by consumer as a result of handling, storage and transportation rules violation. When there are signs of oxidation or other proofs of liquid penetration in the device housing;
- a device with signs of electrical and/or other damages caused as a result of unacceptable changes in external power network parameters or improper use of the device.

The device software is licensed, terms related to the manufacturer's limited liability in the framework of the License Agreement are provided at the web site <http://neomatica.ru/upload/files/license.pdf>

## **10. Marking and packaging**

Marking is placed on the device case. The devices are packed in individual boxes, which protect them during transportation and storage. Multipack is possible.

## 11. Disposal

Device recycling is performed according to national and local norms and requirements.

## 12. Scope of supply

Item name	Quantity	Note
Reader ADM20		
Tag ADM21		
Card 125kHz		
Card 13,56MHz		
Operation Manual		