

FHL

# Vehicle tracker ADM333 BLE GLONASS/GPS-GSM/GPRS

**Operation manual** 

Edition 1.2

Neomatica, +7(342) 211-15-00 ext.42, https://neomatica.com

#### Content

1 Purpose and function	5
2 Technical specifications	6
3 Design	7
3.1 Disassembling and assembling of the housing	9
4 Installation	9
5 Tracker setting	11
5.1 Connection to ADM configurator	11
5.2 Using configuration commands	12
5.3 Configuring SIM	13
5.4 Setting connection to the server	14
5.5 Setting data transmission	14
5.6 Setting route (track) drawing	15
5.6.1 Selecting presets of route drawing quality	15
5.6.2 Expert setting of tracking parameters.	16
5.7 Alarm mode of data record.	17
5.8 Setting the fixation (freezing) of coordinates during the parking	18
5.8.1 Coordinates fixation according to ignition	18
5.8.2 Coordinates fixation according to vibration level	18
5.9 Operation mode	19
5.9.1 "Tracker" operation mode	19
5.8.2 "Beacon" operation mode	19
6 Connection of extra devices	20
6.1 Analogue inputs	20
6.2 Discrete output	21
6.3 Connection of devices via Bluetooth Low Energy	23
6.3.1 Connection of BLE sensors	23
6.3.2 Adding BLE sensors in automatic mode	23
6.3.3 Adding sensors ADM31, ADM 32 in manual mode, viewing added sensors list	25
6.3.3.1 Data receiving from connected ADM31/32 sensors	25
6.3.4 Adding BLE fuel level sensor in a manual mode, viewing added sensors list	27
6.3.4.1 Data receiving from connected fuel level sensors	28
7 Data transmission to the server from connected sensors	29
7.1 Description of ADM31 sensors parameters transmitted to the server	29

7.1.1 Conversion of incoming data at the server side	29
7.2 Selecting data to be transmitted to the server from ADM31/32 sensors	31
7.3 Selecting the transmission format of the illumination level	31
8 Commands description	33
9 Updating tracker software	43
9.1 Updating tracker software via ADM Configurator	43
9.2 Updating tracker software via ADM Configurator using a firmware file	43
9.3 Updating the tracker software via GPRS	44
10 Handling and transportation regulations	44
11 Warranty obligations	44
12 Marking and packaging	45
13 Disposal	45
14 Scope of supply	45
15 Acceptance certificate	45
Appendix A. Description of the bits of the field «STATUS»	46
Appendix B. Description of transmitted parameters in Wialon	47

This Operation manual relates to the vehicle tracker ADM333 BLE (hereinafter referred to as tracker) and describes the procedure of its installation and connection as well as its function and settings.

The Operation manual is designed for professionals who have familiarized themselves with the rules of repair and installation works execution in vehicles and who have special professional knowledge in electronic and electric equipment used on various transport means.

The tracker proper work can be guaranteed if it is installed and set by qualified professionals. To use the tracker properly it is necessary to familiarize with the monitoring system work principles in general and to understand the function of all its components. For this reason, it is strictly recommended to get basic knowledge on GLONASS and GPS global navigation satellite systems functioning, GSM network, issues related to data transmission by means of short message service (SMS), GPRS and Internet.

# **1** Purpose and function

The tracker is intended for installation on a vehicle as an additional device that records the location of the vehicle, its speed, and travel direction. View of the tracker is shown in Figure 1.

Additionally, the voltage level at the analogue inputs and data received from supported sensors connected via radio channel Bluetooth Low Energy. All events and conditions fixed by the tracker are stored in its non-volatile memory.

The accumulated data is transmitted through the GSM 850/900/1800/1900 cellular network operator using packet data transmission technology GPRS to a dedicated server with a static IP address or domain name from which it can be received via the Internet for further analysis and processing in a monitoring center.

The tracker can be configured in any convenient way: locally (via Bluetooth, using the ADM Configurator (hereinafter referred to as Configurator) or remotely (by sending commands via SMS or GPRS).

To ensure data security, when the external power is turned off and the GSM network is lost, the tracker has a non-volatile memory. Data transmission is possible only if there is a GSM 850/900/1800/1900 cellular network supporting a packet data service (GPRS).





The vehicle travel route is described in the form of separate points in time. The route point is saved when at least one event occurs, such as:

- travel direction changes by an angle which is greater than the pre-set one;

- the straight-ahead travel is performed at a distance, which is longer than the pre-set one;
- the pre-set acceleration limit is broken;
- the time for putting the point while traveling (parking) is expired;
- device status change (description is given in <u>Appendix A. Description of the bits of</u> <u>the field «STATUS»</u>);

— an event occurs at analogue input.

In this way, route points might be saved with the time interval from one second to several minutes allowing for a quality routing, recording any changes without a surfeit of information saved in the "black box" and increase in GPRS traffic.

After connection to the power supply, the tracker starts receiving data from GLONASS and/or GPS satellites, locating itself, identifying time, speed, travel direction, and in case of GSM network availability establishes connection with the server. After connection to the server, the tracker transmits the data packets with the pre-set frequency or when an event occurs. If for any reason the connection to the server fails, all the information will be saved in the tracker non-volatile memory and transmitted as soon as the connection is restored.

If there is no signal from GLONASS and/or GPS satellites and there is GPRS connection the time is synchronized via NTP protocol with one of the available public servers. The points will be recorded without data about location.

#### Data transmitted by the tracker:

- GMT date and time;
- coordinates (latitude, longitude, altitude);
- speed, acceleration and travel direction;
- number of satellites when fixing a navigation problem;
- precision loss factor in a horizontal plane;
- voltage values at analogue inputs
- data about events occurred;
- device status;
- data from the sensors connected via radio channel Bluetooth Low Energy

## 2 Technical specifications

- GLONASS/GPS receiver:
  - chipset: MT3333 (MediaTek);

frequency bands: GLONASS – L1 (CT-code), GPS - L1 (C/A code);

sensitivity in cold start/tracking, dBm: - 149 dBm/- 167; number of tracking/picking-up channels: 33/99

positioning precision, 95% of time, not worse: 3 m

- Connection standard: GSM 850/900/1800/1900, GPRS Multi-slot Class 12.
- GSM transmitter power: 2 W
- Number of SIM-cards, form factor: 2, nano-SIM (4FF).
- Number of analogue inputs: 2.
- Analogue inputs features:
  - voltage measurement range: 0...58,8 V
  - discreteness (sensitivity): 57,4 mV
  - input resistance: 200 кОhm.
- Number of discrete outputs of "open collector": 1.
- Characteristics of discrete output of "open collector" type":

maximum voltage - 45V;

maximum commutated current – 100mA.

- Acceleration meter: digital, triaxial
- Battery: Li-Pol 250 мА/h 3.7V (0,9 W/h).
- Number of route records : not more than 20 000.
- PC connection interface: Bluetooth
- Connection interface with wireless sensors: Bluetooth Low Energy.
- Operation temperature:

with a battery: - 20...+60°C;

without a battery: - 40...+85°C.

- Power voltage: +8...+45 V of unregulated direct current
- Current consumption (at the supply voltage 12 V):

maximum: 200 mA

- average: 30 mA
- Dimensions: 55x49x20mm;
- weight: not more than 39 g

# 3 Design

Functionally, the tracker consists of a microcontroller, non-volatile memory, a combined GLONASS/GPS-, GSM-, Bluetooth module, a battery, analog inputs and a discrete output.

**The GLONASS/GPS unit of the combined module** is designed to receive signals from the GLONASS/GPS satellites and determine the geographical coordinates of the receiver antenna (latitude, longitude and altitude), as well as the exact time (GMT), speed and direction of travel.

GSM/GPRS unit of the combined module performs the following functions:

- establishment and maintenance of outgoing TCP/IP connection (data reception and transmission in GPRS mode);
- reception and sending SMS messages.

For information transmission, the GSM/GPRS unit of the combined module establishes and maintains connection to the server, periodically transmitting information packets. The periods of data transmission to the server during the parking and during the movement of the vehicle are different and can be changed by user.

**Bluetooth unit of the combined module** provides connection to the PC, wireless information exchange between the tracker and the ADM Configurator as well as data receipt from wireless sensors.

To display the operating status, the tracker has got 2 LED indicators: green and blue

The green LED indicates the status of the GLONASS/GPS unit of the combined module:

- flashes three times- the GLONASS/GPS unit is on, but there is no data from it;
- flashes twice data from the GLONASS/GPS unit received, but the coordinates are invalid;
- flashes once the GLONASS/GPS unit has determined the time and the valid coordinates.

The blue LED indicates the status of the GSM/GPRS unit of the combined module:

- flashes three times the GSM/GPRS unit is disabled for re-initialization;
- flashes twice the GSM/GPRS unit is on, but there is no connection to the server;
- flashes once the tracker has established connection to the server and successfully transmits the information packets;
- constantly shines, briefly turning off SIM card is not available.

The scheme of tracker connector pins is given in Fig. 2



Fig.2 –Scheme of pins location

# 3.1 Disassembling and assembling of the housing

There are logo and LEDs on the upper part of the housing.

There is a sticker with marking on the lower part of the housing.

## • The disassembling should be done as follows:

- 1. Place the housing on a solid surface in such a way the logo to be upwards
- Insert a card into the gap at the angle of 45 degrees until the housing starts splitting Do not split two parts of the housing at this stage.
- 3. Insert a card into the gap from the other side of the housing at the angle of 45 degrees until the housing starts splitting.
- 4. Take off the lower part of the housing

5. Bending two latches of any side of the housing, lift the scheme up and gently remove it without damaging the wires and the built-in battery.

## • The assembling should be done in the reverse order:

- 1. Make sure the wires of the battery are not squeezed and then install the scheme.
- 2. Pressing to the scheme alternately from both the sides, clamp the scheme holders
- 3. Install the upper part of the housing.

# 4 Installation

It is strongly recommended to carry out a preliminary check of the tracker before installation, using a power supply different from the vehicle on-board power, with an output voltage from 8 V to 40 V DC and current of at least 1 A.

The internal GLONASS/GPS and GSM antennas are used in the tracker, which allow its installation almost in any place of the vehicle. However, it is not recommended to install it in the places where the received signals will be attenuated by the vehicle metallic housing, since this may affect the tracker working quality. For a proper function of the receiver GLONASS/GPS, put the tracker so that its sticker is directed upwards.

Insert into the holder a SIM card SIM0 with a deactivated PIN code request, activated data transmission service via GPRS, SMS and sufficient balance for these services.

Supply the power to the tracker according to the layout in Figure 3 and the scheme of pins location in Figure 2. When connecting the plus of the vehicle network to the tracker, install a 2A fusible as close as possible to the point of connection to the vehicle network, which is especially important when connecting directly to the battery clamp.



Figure 3 – Standard connection layout of the tracker

If there are valid satellite data and an established connection to the server, the tracker will catch the time, coordinates and transmit information packets to the server, which will be marked by a single flashing of the green and blue LEDs.

# **5 Tracker setting**

## 5.1 Connection to ADM configurator

To connect the ADM333 tracker to a personal computer using Bluetooth wireless technology, do the following:

- 1) Bring the Bluetooth adapter of the PC to the working state;
- Start the ADM Configurator program of the version 2.4.3 or later (available for loading in website http://neomatica.com);
- 3) Switch the ADM Configurator to the Bluetooth radio connection mode. To do this, you need to select the way to connect the device by clicking on the Bluetooth icon in the upper left corner of the ADM Configurator, as shown in Figure 4;



# Select method of device connection

Figure 4 - ADMConfigurator: choosing how to connect the device

- 4) Supply power to the tracker;
- 5) If there are several active trackers within the reach of the Bluetooth adapter of the personal computer, select the "Select device" flag and enter the last 4 digits of IMEI as shown in Figure 5. If there is only one tracker within the reach of the Bluetooth adapter of the personal computer it is possible to remove "Select device" flag. In such a case a random tracker from all the detected ones will be connected.



Рисунок 5 – ADM Configurator waiting for device connection

- After a few seconds the connection between the tracker and the ADM Configurator program will be installed and the settings window will be displayed;
- 7) After the device is set or, if connection of another tracker is required, click "disable device" in the upper right corner of the ADM Configurator. The ADM Configurator will go into a standby mode as shown in the Figure 6.

		Time UTC:	20.05.2019 11:23:48	GLONASS	5	i	?	$\square$
	NEOMATICA	Latitude:	57.997753	Q GPS:	5	Г	.h	
		Longitude:	56.194061	GSM:		4	*×	
Device:	ADM333BLE							
Firmware version:	0x01 Fistory		सि 🕅 🕂					

Figure 6 – ADM Configurator: "disable device button"

## **5.2 Using configuration commands**

The tracker is managed by commands sent via SMS, GPRS or Bluetooth. Commands syntax is the same for any way of transmission.

## General rules of writing and sending commands:

- only Latin characters and punctuation can be used in commands;
- character case does not matter;
- commands transmission syntax is the same for SMS, GPRS and Bluetooth;
- commands syntax: «CMD X1,X2,X3», where CMD is a command, X1..X3 are commands parameters;
- commands are separated by a SPACE. Parameters are separated by commas, except for the DN0 command which parameters are separated by a colon;

After receiving a command, the tracker performs it and sends a feedback.

If the command parameters extend beyond the acceptable range, the tracker changes them to the nearest acceptable values. If it is not possible to change parameters or parameters are not enough, the tracker will answer with an error message. A command without parameters returns the current settings.

#### — Sending commands using ADM Configurator

To send commands via Bluetooth you should use ADM Configurator. If earlier the tracker under configuration had a password different from 0, then ADM Configurator will ask for the password.

#### — Sending commands using SMS

To manage the tracker using SMS, it is necessary to send the SMS command "**ADD ME 0**" to the number of the SIM card installed in the tracker, where 0 (zero) is the default password (if the password has been changed, you should enter it instead of 0). The phone number from which this command was sent will be authorized in the tracker. The authorization is done only once, afterwards the tracker saves the phone number in a non-volatile memory during the whole service life. Maximum quantity of saved phone numbers is 4. Resetting the settings to the factory ones clears all phone numbers.

#### — Sending commands using TCP connection

To configure via GPRS, authorization is not required. The tracker receives the commands from the server via TCP-connection that is used for data transmission.

## 5.3 Configuring SIM

Enter parameters of the access point name (APN) in the ADM Configurator graphic interface for the installed SIM cards or use commands **SETGPRS0** and **SETGPRS1**, the final digit in a command name corresponds to the phone number of a holder's SIM card.

If the installed SIM card/cards is/are with enabled PIN -code, then enter this PIN-code in the ADM Configurator graphic interface or use commands **PIN0** and **PIN1**, the final digit in a command name corresponds to the phone number of a holder's SIM card. This PIN-code will be automatically entered each time a Sim card initialization is required.

There is an opportunity to select a priority SIM card when using two Sim cards. If the priority is set, then the tracker connecting to the server using a non-priority SIM card, will work via it for 30 minutes, then will switch to the priority one and, if the connection to the server is established, will work via it without time limit. The priority is set in the graphic interface of the ADM Configurator or using **SIMPRIORITY** command. By default, priority is not set.

#### 5.4 Setting connection to the server

Configure the IP address and port of the server (host) using **«SETHOST0**» or **"DN0"** command.

Change of these parameters is possible in the graphical interface of the program "ADM Configurator".

## 5.5 Setting data transmission

Navigation data and data received from different sensors being transmitted from the tracker to the server, are divided by data packets. Depending on the functionality used, it is necessary to activate the transmission of the necessary data packets.

The setting is done in the graphic interface of the ADM Configurator or by **PROTOCOL** command.

Table 1 shows the correspondence of data packets to the values of **PROTOCOL** command. If data transmission is required to be transmitted from several packets then calculate **PROTOCOL** command parameter by addition. To save the traffic it is recommended to set only the transmission of necessary data packets.

For example:

Main data (0) +analogue inputs (8) +fuel level sensors (32) = PROTOCOL 40

Data packet name		Parameter value
Main data	NAVIGATION DATA	0
Outputs, events in inputs	OUTS	4
Analogue inputs	IN_A	8
Fuel level sensors	FUEL	32
Can	CAN	64

Table 1. Values of the main parameters for PROTOCOL command

## 5.6 Setting route (track) drawing 5.6.1 Selecting presets of route drawing quality

To facilitate the process of setting the route drawing quality there are several factory presets. The preset can be selected in ADM Configurator (version 2.4.5 at least) or by **TRACKSET** command. The presets contain several sets of parameters. In total 5 presets are available. All presets allow to get a drawing of the travel path, the differences are in the degree of route details. The more detailed route is the more route points will be transmitted to the server, this increases the traffic consumption. Less detailed route reduces traffic consumption.

#### • TRACKSET command description:

#### TRACKSET X

X –number of route drawing preset

X = 0..4

In response a total list of set parameters will be displayed. Answer example: TRACK 4,1000,100; (1):3,5; (2):3,5; (3):3,5 Command without parameters displays current route settings.

#### Presets description:

#### **TRACKSET 0**

Satisfactory tracking quality, money-saving variant as regards route points and traffic consumption. The quality is enough to monitor the movement path. The drawing of road turns is simplified. Slight route changes are not drawn (expected points per km are twice less than in preset 2).

#### TRACKSET 1

A good tracking quality. The drawing of slight changes of direction and road turns is simplified (expected points per km are 1.3 times less than in preset 2)

#### **TRACKSET 2**

Set by default. A good tracking quality. The variant suits to the most of tasks. Is an average variant as regards tracking drawing quality and traffic consumption. Slight direction changes and road turns are drawn with details.

#### **TRACKSET 3**

Slight changes in direction are drawn with more details (expected points per km are 1.3 times more than in preset 2)

#### **TRACKSET 4**

High tracking detailzation. Slight changes in direction are drawn with many details. (expected points per km are 1.6 times more than in preset 2)

#### 5.6.2 Expert setting of tracking parameters.

It is recommended to use this method of setting only if none of the presets fit the task. The change of these parameters can lead to an increase of traffic consumption or to a decrease of the route drawing quality.

#### Setting using TRACK command

To set all the parameters send TRACK command twice. The degree of road turns detalization is set by sending TRACK command with three parameters. Command format: TRACK M,A,B

The threshold values of additional circumstances of route points drawing in movement are set by sending TRACK command with four parameters. Command format: TRACK 255,X,Y,Z

# Setting the degree of road turns drawing detalization. Setting threshold values of angle change and deflection.

A route point is drawn when the threshold values are exceeded.

#### TRACK M,A,B

M – number of speed mode.

- M=255 apply same parameters for all the modes
- M=0 slow movement
- M=1 medium -speed movement
- M=2 fast movement
- A angle for speed mode with M number.
- B deflection for speed mode with M number.

The threshold values of angle change and deflections are set separately for three speed modes. If same values should be set for all speed modes then the command should be sent once, M parameter in this case equals to 255. If different threshold values should be set for three speed modes then the command should be sent 3 times, choose speed mode using M parameter.

Example

#### Setting same parameters for all speed modes:

TRACK 255,10,6 – Set 10 degrees for the threshold value of route change and 6 for deflection

• Setting different parameters for all speed modes:

TRACK 0,20,7 – Set 20 degrees for the threshold value of route change and 7 for deflection of slow speed mode.

TRACK 1,10,6 – Set 10 degrees for the threshold value of route change and 6 for deflection of medium speed mode.

TRACK 2,5,6 – Set 5 degrees for the threshold value of route change and 6 for deflection of fast speed mode.

#### • Setting minimum speed, distance and acceleration.

If the set threshold values are exceeded, a route point will be recorded.

TRACK 255, X,Y,Z – First parameter should always be equal to 255. For all speed modes these parameters are the same.

X - minimum speed

- Y distance (meters)
- Z acceleration (km/h per second)

#### Viewing set parameters

TRACK – Display current settings.

The response displays minimum speed, distance, acceleration, angle and deflection for three speed modes.

Response format: TRACK X,Y,Z; (M) A1,B1; (M) A2,B2; (M) A3,B3

X - minimum speed

- Y distance (meters)
- Z acceleration (km/h per a second)

M=0 - slow movement

- M=1 medium speed movement
- M=2 fast movement
- A angle for speed mode with M number
- B deflection for speed mode with M number

Answer example: TRACK 4, 1000,

#### 5.7 Alarm mode of data record.

The tracker switches to the alarming mode of data record when the sensors data are beyond the set range. Such a mode does not affect other conditions of routes record. Drawing of the tracking routes stays a priority. If other conditions for route points record are not performed then the points will be recorded according to the alarm period.

Such a function allows fixing the moment when sensor values are beyond the acceptable range as well as recording in more details the values changes outside the allowed range.

#### — Setting the period of route points record at the alarm mode.

#### ALARMPERIOD X

X – period of route points drawing in seconds

Command without parameters shows the set value

## 5.8 Setting the fixation (freezing) of coordinates during the parking

The margin of error in coordinates determination might cause a slight coordinates dispersion (GPS drifts) during a long-term parking of the vehicle. To prevent this effect the coordinates freezing function might be applied in the beginning of the parking. This mode is enabled automatically when the discrete level is changed at the analog input or when there is no vibration. Location fixation (freezing) according to the vibration values is chosen by default. It is impossible to use simultaneously two ways of coordinates fixation. The tracker fixes the coordinates according to the last mode.

## 5.8.1 Coordinates fixation according to ignition

To enable the fixation coordinates function when the vehicle ignition is switched off, it is necessary to connect to the analogue input a circuit being under voltage when the ignition is on. Activation of this mode and selection of the input are made by the **"INSTATIC"** command. For this analogue input it is necessary to activate a discrete working mode and set values range of the voltage level for the logical «1» «**INTRUE**» and the logical «0» «**INFALSE**». Then choose the mode of coordinates fixation according to ignition and a number of the input the ignition is connected to. In this way, when the ignition is off, an event will be formed at the input and the coordinates fixation will be initiated.

Examples of using INSTATIC command:
 Coordinates fixation at 0 on input AIN0 INSTATIC 0,0
 Coordinates fixation at 0 on input AIN1 INSTATIC 1,0
 The function is disabled by «INSTATIC 255» command

## 5.8.2 Coordinates fixation according to vibration level

In such a mode coordinates fixation is done automatically at the absence of vibration. Current level of vibration (a sum of acceleration on three axes) is determined by the acceleration meter.

If the vibration level is below the threshold within 10 seconds (by default) the coordinates are fixed.

The function is enabled by **ACCELSTATIC 10** command.

The function is disabled by ACCELSTATIC 255 command.

## 5.9 Operation mode

The tracker has got two modes of routes record: «Tracker» and «Beacon». The working mode is set by **BMODE** command. Mode "Tracker" is set by default.

#### **BMODE X**

X=0 - «Tracker» mode.

X=1 - «Beacon» mode.

## 5.9.1 "Tracker" operation mode

This mode is used to create (draw) exact path of travel.

The routes record is done using all possible criteria:

- change of speed;
- acceleration threshold exceeding;
- distance passage;
- direction change;
- regarding the period of movement;
- regarding the period of parking;
- at tracker start up;
- change of discrete state at input;
- change of device status

## 5.8.2 "Beacon" operation mode

This mode is used to record routes at a given time period and is not suitable for the creation of exact path of travel. Time period of routes record equals to the period of routes record while parking. The routes record is done only using the following criteria:

- at tracker start up;
- change of discrete state at input;
- regarding the parking period;
- regarding alarming period;
- change of device status

# 6 Connection of extra devices

## 6.1 Analogue inputs

The analog inputs IN0 and IN1 can be used to connect analog type sensors and voltage measurement, and can also be interpreted as discrete.

Voltage measurement range: 0...58.8 V.

Discreteness (sensitivity): 57.4 mV.

Minimum input resistance: 200 kOhm.

It is forbidden to apply voltage exceeding the upper limit of the measuring voltage range

If it is necessary to record a certain voltage level, for example, in the ignition switching circuit, activate discrete operation mode and set values of voltage level for the logical "1" with the **INTRUE** and for the logical "0" with **INFALSE** 

#### Description of the commands:

#### INFALSE IN, X0, Y0

IN - number of the analog input (always specify 0)

X0 - the lower limit of the logical "0" voltage range (fixed value 0mV)

Y0 – the upper limit of the logical "0" voltage range (variable value)

#### INTRUE IN, X1, Y1

IN - number of the analog input (always specify 0)

X1 - the lower limit of the logical "1" voltage range (variable value)

Y1 - the upper limit of the logical "1" voltage range (fixed value of 60000 mV). When entering these commands, the voltage must be specified in millivolts.



Figure 7 - Bands of discrete states

If the voltage level is in the zone of indifference, the previous discrete state is maintained until the level goes beyond the zone of indifference.

The measured voltage levels are registered by the tracker and transmitted to the server.

When changing the discrete state, an extraordinary packet is sent.

## 6.2 Discrete output

Output type - open collector

Maximum voltage - 45 V

Maximum commutated current – 100 мА.

Discrete output allows handling extra equipment. When switched on, the output is connected to the minus of the tracker external power supply. Connection should be done according to the scheme in Figure 9.



Figure 9 – Scheme of the connection of charge with the current consumption not more than 100mA.

It is allowed to connect devices with the maximum current consumption not exceeding 100mA, otherwise there is a risk to damage the tracker. When a more powerful load commutation is needed, it is necessary to use a relay.



Figure 10 - Scheme of the connection of load with the current consumption exceeding 100mA

To prevent the tracker output from self-induction pulses, which appear after switching off the inductive load, including the relay coil, it is necessary to connect a diode parallelly to the relay coil in the opposite direction.

It is possible to control the output condition with the OUTPUT X command

X=1 – switch on (to short output to ground),

X=0 – switch off (to put output in a state of breakage).

## 6.3 Connection of devices via Bluetooth Low Energy

Connection of extra devices to the tracker assumes a set of actions: to configure the device under connection, the tracker and PC at the side of the server.

The server receives correct values from the connected sensors provided all steps are performed correctly:

- Configuring the sensor/devices (in case of necessity).
- Setting communication between the tracker and the sensor. Ways of supported sensors connection are given in clause <u>6.3.1</u>.
- Activation of necessary data transmission from a tracker to a server. For description and data transmission choice see clause <u>5.4</u> and clause <u>7.1</u>.
- Setting transformation of received data on the server side. (in case of necessity). See detailed description in clause <u>7.1.1</u>.

#### 6.3.1 Connection of BLE sensors

The configuration of the sensor interaction with the tracker is done in the ADM Configurator graphical interface or by sending commands to the tracker via Bluetooth, GPRS or SMS. Up to 5 ADM31/32 sensors and 3 BLE fuel level sensors can be connected simultaneously to one tracker.

There are two ways of binding the sensor to the tracker - manual and automatic.

In manual mode, you need to enter the addresses of each of the sensors. This method is suitable for the situation when there are active sensors in the Bluetooth receiving area of the tracker and they shouldn't be bound to this tracker.

In automatic mode, sensors are searched for and the addresses of all the sensors found are automatically recorded. This method is suitable for a situation when only the required sensors are in the receiving area of the Bluetooth tracker.

#### 6.3.2 Adding BLE sensors in automatic mode

The **BLEAUTOCATCH** command starts the search and automatic record of the found sensors addresses to the BLESENSOR and BLEFUEL lists. By default, the search is performed within two minutes according to the filter as regards radio signal level minus 60 dBm. Such a filter mode allows adding sensors located at the distance of 0 to 0,5 meters from the tracker. Examples of using commands:

**BLEAUTOCATCH** – automatic search by default, with the filter as regards the signal level.

**BLEAUTOCATCH 255,0** – automatic search of all supported sensors without filters.

BLEAUTOCATCH 0 - stop the current search

## 6.3.2.1 Additional parameters of automatic sensors search

In case of necessity the criteria of automatic search can be changed by entering certain parameters. **BLEAUTOCATCH** command has 4 parameters D, F, R, T.

Description of parameters of **BLEAUTOCATCH D,F,R,T** command :

• D – sensor type.

When entering such a parameter only the sensors of the indicated type will be added. Table 2. shows the correspondence of values to the BLE sensors types. In case several sensors types should be bound simultaneously then add several needed parameter values.

Table 2. Types of supported BLE sensors.

Sensor type	Parameter value
ADM31, ADM32	1
ESCORT fuel level sensor (BLE)	2
Technoton fuel level sensor BLE (DUT-E)	4
Technoton axis load sensor BLE (GNOM)	8
All types of the supported sensors	255

• R –RSSI level

Acceptable filter range from minus 1 to minus 127 dBm.

Entering value without a character is acceptable from 1 to 127.

• T – search time in seconds.

Acceptable range of search duration from 10 seconds to 120 seconds.

#### 6.3.2.2 Usage options of «BLEAUTOCATCH» command.

• Search within 120 seconds, without the filter according to radio signal level minus 60 dBm. **BLEAUTOCATCH** 

• Search with the opportunity to choose the sensor type (D), without the filter according to radio signal level, search time of 120 seconds.

#### **BLEAUTOCATCH D**

• Search with the opportunity to choose the sensor type (D), to switch off the filter according to radio signal level (F), search time of 120 seconds.

#### **BLEAUTOCATCH D,R**

• Search with the opportunity to choose the sensor type (D), to set the filter according to the distance (R), search time 120 seconds.

#### **BLEAUTOCATCH D, F, R**

• Search with the opportunity to choose the sensor type (D), to set the filter according to the distance (R), to choose the search time (T).

#### **BLEAUTOCATCH D,R,T**

#### 6.3.3 Adding sensors ADM31, ADM 32 in manual mode, viewing added sensors list

The **BLESENSOR** command allows to add sensor addresses, as well as to view the list of added addresses. The sensor address is marked on the label placed on the housing.

Don't enter a colon when entering the address.

BLESENSOR X,Y - add address Y to the cell X, where X=0..4;

**BLESENSOR X,0** - clear cell X, where X = 0..4;

BLESENSOR Y - add address Y to the end of the list;

BLESENSOR 0 - clear the list;

**BLESENSOR** – display the list of addresses added to the tracker.

Example of commands input:

BLESENSOR 0,FC61CFEF5E31 – add address FC:61:CF:EF:5E:31 to the cell 0;

BLESENSOR FC61CFEF5E31 – add address FC:61:CF:EF:5E:31 to the end of the list.

## 6.3.3.1 Data receiving from connected ADM31/32 sensors

The **BLESENSORINFO** command allows to request the latest data received by the tracker from the sensor.

**BLESENSORINFO X** – displays the data of the sensor under number X, where X is the number of the device from the BLESENSOR sensors list.

**BLESENSORINFO** - command without parameter displays information about all the configured sensors;

Example of the answer:

BLESENSORINFO: [0]:DD9DD495C467; DT:2; PT:1; F:1; V:3.2; A:1; R:-35; LMT:20; S:0; [1]:EE53F61FCC05; DT:0; PT:0; F:0; V:25.5; T:-300.00; L:655.35; H:255, R:0; LMT:0; S:32768;

Description of answer parameters:

Fields, general for all types of sensors ADM3x.

Sensor address

DT – type of the device.

PT – type of the packet.

F - software version.

V - battery voltage.

R – level of RSSI in dBm.

LMT – time passed from the receipt of the last message from the sensor.

S – sensor status.

#### ADM31

T - temperature.

L - illumination.

H - humidity.

#### ADM32

A – angle value in degrees.

## 6.3.3.2 Setting the acceptable readings range for ADM31/32 sensors

When the readings are beyond the acceptable range the tracker will switch to the route points record at an alarm period.

Setting the acceptable temperature range.

#### **TEMPRANGE X, A, B**

Parameter X – device number (from BLESENSOR sensors list). Parameters A and B – limits of the acceptable temperature range. Parameters A and B can be omitted- current range will be displayed.

Setting the acceptable humidity range.

#### HUMIDRANGE X, A, B

Allows to set the acceptable humidity range of the sensor. Parameter X - device number (from sensors list). Parameters A and B – limits of the acceptable humidity range. Parameters A and B can be omitted- current range will be displayed

Setting the acceptable illumination range.

#### LIGHTRANGE X, A, B

Parameter X – device number (from BLESENSOR sensors list).

Parameters A and B - limits of the acceptable illumination range.

Parameters A and B can be omitted- current range will be displayed

Setting upper and lower sensor states. When there is a changeover between the states an extra point is drawn.

#### ANGLERANGE X, A, B, C, D

X - device number (from BLESENSOR sensors list).,

A, B – lower and upper limits for "lower" sensor state.

C, D – lower and upper limits for "upper" sensor state.

# 6.3.4 Adding BLE fuel level sensor in a manual mode, viewing added

## sensors list

«BLEFUEL» command allows to add sensors addresses as well as to view the list of added sensors. No need to enter a colon when entering an address.

**BLEFUEL X,Y** – add address Y to cell X, where X=0..2;

**BLEFUEL X,0** – clear cell X; where X=0..2;

BLEFUEL Y - add address Y to the end of the list,

BLEFUEL 0 – clear the list.

**BLEFUEL** - display the list of addresses added to the tracker.

Example of commands input:

BLEFUEL 0,E5F2A9527B1D - add address E5:F2:A9:52:7B:1D to cell 0;

BLEFUEL E5F2A9527B1D – add address E5:F2: A9:52:7B:1D to the end of the list.

## 6.3.4.1 Data receiving from connected fuel level sensors

**BLEFUELINFO** command allows to require the latest data, received by the tracker from the sensor.

**BLEFUELINFO X** – data display from the sensor number X, where X – device number from the BLEFUEL sensors list.

BLEFUELINFO – command without parameters displays the data from all set sensors.

Answer example: BLEFUELINFO: [0]:0018E9C64433; DT:4; F:7; L:27; T:23; DTC: 0; LMT:5; R:-67

#### Decoding of the answer for ESCORT TD-BLE:

- DT device type
- T temperature
- L fuel level
- V current battery voltage value of the fuel level sensor
- F software version
- LMT time passed since the last message from the sensor was received
- R RSSI

#### Decoding of the answer for DUT-E:

- DT device type
- F software version
- L fuel level
- T temperature
- DTC failure mask. Fields of the mask are described in the sensor protocol
- LMT time passed since the last message from the sensor was received
- R RSSI

#### Decoding of the answer for GNOM:

- DT device type
- F software version
- P pressure characteristics in the pneumatic system
- T temperature

DTC – failure mask. Fields of the mask are described in the sensor protocol LMT – time passed since the last message from the sensor was received R - RSSI.

# 7 Data transmission to the server from connected sensors7.1 Description of ADM31 sensors parameters transmitted to the server

Data from ADM31/32 sensors is transmitted in CAN data packet together with other data in each message. There are 5 CAN fields for each sensor. The correspondence of CAN fields to the transmitted data type is given in table 3. The sensor number given in the table corresponds to the number of the added sensors list.

Table 3. Description of transmitted data from ADM31 sensors

Sensor 0	Sensor 1	Sensor 2	Sensor 3	Sensor 4	Parameter
can1	can6	can11	can16	can21	Temperature
can2	can7	can12	can17	can22	Humidity
can3	can8	can13	can18	can23	Illumination level
can4	can9	can14	can19	can24	Battery voltage
can5	can10	can15	can20	can25	Hall sensor

Table 4. Description of transmitted data from ADM32 sensors

Sensor 0	Sensor 1	Sensor 2	Sensor 3	Sensor 4	Parameter
can1	can6	can11	can16	can21	Angle
can4	can9	can14	can19	can24	Battery voltage

## 7.1.1 Conversion of incoming data at the server side

Since CAN data packet is universal, calculation formulas are not applied to these fields on the servers.

To convert values to a readable format, the following calculation formulas described below should be applied to the incoming values.

To prevent values jumps when there is no communication with the sensors, it is recommended to set a range of permissible values on the software side. Or apply other filters supported by the software you use.

#### • Temperature

Use 2 formulas to calculate two ranges of incoming values:

For the range values from 0 to 32767 – apply formula X\*0.01

For the range values from 32768 to 65535 - apply formula X\*0.01-655.36

To display negative and positive values correctly use both formulas for the corresponding ranges.

Acceptable values range after formula calculation is -39...+150

-300 value (after formula calculation) is considered as an error code «no signal from sensor».

#### **Humidity level**

Conversion is not needed. Acceptable values range 0 - 100 255 value is considered as an error code «no signal from sensor».

#### illumination level

— Shortened format (by default).

There is no need for conversion in case of using a shortened format.

Acceptable values range is 0 – 65534.

65535 value is considered as an error code «no signal from sensor».

- Full format.

When using a full format apply formula X\*0.01.

Acceptable values range after calculations is 0.00 - 83866.00

42949672.95 value (after formula calculation) is considered as an error code «no signal from

#### sensor».

Setting the format of illumination level transmission is described in clause 7.3 Selecting the transmission format of the illumination level.

#### Battery voltage

Apply formula X\*0.1.

Acceptable values range after calculations is 0 - 4

25.5 value (after formula calculation) is considered as an error code «no signal from sensor».

#### Hall sensor (magnetic field detector)

Conversion is not needed.

Acceptable values range is 0 - 1.

## 7.2 Selecting data to be transmitted to the server from ADM31/32 sensors

Depending on the functionality use of the BLE sensors ADM31/32, it is possible to disable the transmission of unnecessary fields to the server. Correspondence of the fields to parameter values of **BLEPROTOCOL** command is given in table 5. If you want to transmit data from several packets, the X parameter of the **BLEPROTOCOL X** command is calculated by addition. It is possible to use any options.

Transmission of all fields are set by default.

To save the traffic activate only the transmission of necessary fields.

Data packet	Fields name at the server	Parameter value
All data		255
Temperature/Angle	CAN1, CAN6, CAN11, CAN16, CAN21	1
Humidity	CAN2, CAN7, CAN12, CAN17, CAN22	2
Illumination	CAN3, CAN8, CAN13, CAN18, CAN23	4
Battery voltage	CAN4, CAN9, CAN14, CAN19, CAN24	8
Hall sensor	CAN5, CAN10, CAN15, CAN20, CAN25	16

Table 5. Value of BLEPROTOCOL parameter

## 7.3 Selecting the transmission format of the illumination level

To save the traffic consumption a shortened range of illumination level values is transmitted by default. In case of necessity to use full range, activate it. Setting is done by **LIGHTPROTOCOL X** command.

#### LIGHTPROTOCOL X

X = 0,1 - transmission format of illumination values

#### 0 – shortened value format:

Discreetness: integer value

Values range: 0...65534.

Sensor data greater than 65534 are considered to be equal to this value.

65535 value is considered as an error code «no signal from sensor».

#### 1 – full value format

Discreetness: two decimal places

Values range: 0.00 - 83865.60

42949672.95 value (after formula calculation) is considered as an error code «no signal from sensor».

# 8 Commands description

Table 6. Commands description

	Command	Answer	Parameters	Description
1	Name X	Device Name 'X '	X – tracker name	Set the name of the tracker. The name can
	Example:	Example:		contain only letters of the Latin alphabet
	Name bus8	Device Name 'bus8'		and numbers. The name cannot exceed 10
				digits in length. The tracker name is added
				to the alarm SMS messages.
2.1	ADD ME X,Y (only via	PHOES (0)= (1)= (2)= (3)=	X – password, the default is	Authorize the phone number from which the
	SMS)	Example:	"0".	SMS was received and write it to the
	Example:	PHONES (0) =	Y=03 - number of the	memory cell Y. The command is needed
	ADD ME 1234	+7xxxxxxxx (1) = (2)= (3)=	memory cell to store the	only to create a list of numbers to control
	ADD ME 1234,2	PHONES $(0) = (1) = (2) =$	number. Optional	the tracker via SMS.
		+7xxxxxxxx (3)=	parameter.	
2.2	ADD ME X,Y (only via	PHOES (0)= (1)= (2)= (3)=	X – phone number	Adding a phone number from which you
	Bluetooth and GPRS)	Example:	Y=03 - number of the	plan to manage the tracker via SMS.
	Example:	PHOES (0)= (1)=	memory cell to store the	
	ADD ME +7xxxxxxxxxx,1	+7xxxxxxxx (2)= (3)=	number	

	Command	Answer	Parameters	Description
3	PHONES X	PHOES (0)= (1)= (2)= (3)=	X – password, default is "0".	Request a list of authorized phone numbers
	Example:	Example:		
	PHONES 1234	PHONES (0)= (1)=		
		+7xxxxxxxx (2)= (3)=		
4	PASS X,Y	Pass=X,Y	X – old password, default	Change the password from the old X to the
	Example:	Example:	X=0.	newY.
	PASS 0,86974543	Pass=86974543	Y – New password.	The password is a number from one to eight
				digits
5	STATUS	Example:	Command without	Query the current state of the tracker.
		ID=1 Soft=0x1A GPS=9291	parameters.	ID - the number of the tracker,
		Time=11:21:39 25.02.10		Soft - the software version,
		Nav=0 Lat=57.2359		GPS - the current number of the information
		Lon=56.2593 Speed=0.0		packet,
		SatCnt=5 Stat=0x0000		Time - current time and date according to
				Greenwich Mean Time,
				Nav- validity of coordinates,
				Lat - latitude,
				Lon - longitude,
				Speed-speed,
				SatCnt - number of satellites,
				Stat - status.

	Command	Answer	Parameters	Description
6	IMEI	IMEI	Command without	Request IMEI of GSM-module installed in
	Example:	Example:	parameters.	the tracker. The command runs 20 seconds
	IMEI	IMEI 359587013832624		after the tracker is switched on or restarted.
7	SN X	SN X	X –settable tracker ID	Set the tracker ID.
	Example:	Example:		
	SN 123456789	SN 123456789		
8	PIN0 X	PIN0 X	X – pin code of Sim card	Set the PIN code of the SIM card.
	Example:	Example:		
	PIN0 1234	PIN0 1234		
9	PIN1 X	PIN1 X	X – pin code of Sim card	Set the PIN code of the SIM card 1.
	Example:	Example:		
	PIN1 1234	PIN1 1234		
10	SIMPRIORITY X	SIMPRIORITY X	X=0 – no priority.	Set the priority of SIM card
	Example:	Example:	X=1 – priority of SIM0.	
	SIMPRIORITY 0	SIMPRIORITY 0	X=2 – priority of SIM1.	
11	ICCID	ICCID	Command without	Request of ICCID of installed SIM cards
			parameters	

	Command	Answer	Parameters	Description
12	SETGPRS0 X,Y,Z	GPRS0: APN=X, user=Y,	X – access point, by default	Set APN settings for the SIM card. A
	Example:	pass=Z	X=internet.beeline.ru;	command without parameters returns the
	SETGPRS0	Example:	Y - login, default Y=beeline;	current GPRS settings for the SIM card.
	internet.mts.ru,mts,mts	GPRS:	Z – password, default	
		APN=internet.mts.ru,	Z=beeline.	
		user=mts, pass=mts		
13	SETGPRS1 X,Y,Z	GPRS1: APN=X, user=Y,	X – access point, default	Set APN settings for the SIM card. A
	Example:	pass=Z	X=internet.beeline.ru;	command without parameters returns the
	SETGPRS0	Example:	Y - login, default Y=beeline;	current GPRS settings for the SIM card 1.
	internet.mts.ru,mts,mts	GPRS:	Z – password, default	
		APN=internet.mts.ru,	Z=beeline.	
		user=mts, pass=mts		
14	SETHOST0 X,Y	HOST0=X,Y	X - IP adress,	Configuring the IP address and port of the
	Example:	Example:	Y - server port.	server to which the tracker connects to
	SETHOST0	HOST0=134.236.21.2:1230	Five numbers separated by	transmit information. A command without
	134,236,21,2,12300	0	commas.	parameters returns the current server
				address and port.
15	DN0 X:Y	HOST0=X:Y	X - domain name of the	Configure the domain name and port of the
	Example:	Example:	server,	server to which the terminal connects to
	DN0 www.test.ru:1000	HOST0= www.test.ru:1000	Y - server port.	transmit information. A command without
				parameters returns the current server
				address and port.

	Command	Answer	Parameters	Description
16	PROTOCOL X	PROTOCOL X	X – number determining a	Configure the set of data to be transmitted
			data set to be transmitted	to the server. (detailed description see in
				clause 5.5 Setting data transmission)
17	BMODE X	BMODE X	X=0 – mode "Tracker".	Choose the tracker working mode (mode
			X=1 - mode "Beacon".	of points record)
18	TRAFFIC X	TRAFFIC X	X=060- time in seconds.	Set the delaying time before sending a
			By default is X=6	packet to the server for points grouping.
19	ERASE FLASH	ERASE FLASH	Command without	Erase all information packets stored in the
			parameters	memory. After executing this command, the
				current information packet number is reset,
				the tracker is rebooted.
20	ERASE EEPROM	ERASE EEPROM	Command without	Restore the tracker factory settings and restart
			parameters	the tracker.
21	PERIOD X,Y	PERIOD min=X, max=Y	X – the recording period	Set the recording period of information
	Example:	Example:	during the movement in	packets during driving and parking.
	PERIOD 20,120	PERIOD min=20, max=120	seconds, default X=30.	A command without parameters returns
			Y – the recording period	current settings.
			during parking in seconds,	
			by default Y=300.The value	
			of X must be less than Y.	

	Command	Answer	Parameters	Description
22	TRACKSET X	The response displays a	X= 04	Select the preset of route drawing quality.
		detailed configuration of all		For more details see clause 5.6.1
		the set parameters of the		Selecting presets of route drawing quality
		travel drawing		
23	InTrue X,Y,Y	InTrue X,Y,Y	X=0 – input number (always	Set the voltage range of the logical "1" in the
			0);	analog input.
	Example:	Example:	Y – minimum range limit in	
	InTrue 0,10000,60000	InTrue 0,10000,60000	mV;	
			Y=60000 – the maximum	
			range limit in mV	
			(unchanged value).	
24	InFalse X,Y,Y	InFalse X,Y,Y	X=0 – input number (always	Set the voltage range of logical zero in the
			0). Y – minimum range limit	analog input.
	Example:	Example:	in mV; Y – maximum range	
	InFalse 0,0,4000	InFalse 0,0,4000	limit in mV.	
25	InInfo X	Example: Input 0: InTrue	X=0 – input number (always	Request information about the input
	Example:	800015000, InFalse	0).	settings.
	InInfo 0	03000		
26	INPUT	INPUT0 = 12000	Command without	Request current measured voltage level in
			parameters	the analog input (mV).

	Command	Answer	Parameters	Description
27	INSTATIC X,Y	INSTATIC X,Y	X=0 – input number,	Set the input number to enable the
	Example: INSTATIC 1,0	Example: INSTATIC 1,0	Y=0, 1 – activation by zero	coordinates fixation mode. A command
			or one.	without parameters returns the current
			X=255 –disabled function;	setting. By default, no one input is set to
				enable coordinates fixation mode.
28	ACCELSTATIC X,Y,Z	ACCELSTATIC X,Y,Z	X – timeout to enable static	Enabling and disabling coordinates fixation
		Example: ACCELSTATIC	mode (in seconds)	according to vibration level. Set the
	Example: ACCELSTATIC	10	X=255 -disabled function	coordinates fixation parameters according
	10		Y – acceleration threshold to	to vibration level.
			get out from static mode	
			(mg)	
			Z – timeout to get out from	
			static mode in counting	
29	Ουτρυτ χ	OUTPUT X	X=1 – output is active	Control of tracker output. Command
	Example: OUTPUT 0	Example: OUTPUT 0	X=0 – disabled output.	without parameters returns the current
		·		output settings.
30	RESET	reset	Command without	Restart of the unite
			parameters	
31	UPDATE	start update	Command without	Firmware renewal
			parameters	

	Command	Answer	Parameters	Description
32	2 BLEAUTOCATCH D,F,T BLEAUTOCATCH is D – sensor type		D – sensor type	Start the search and automatically bind all
		started. Time: 120 sec; Dev.	F – filter	found sensors ADM31, ADM32. (detailed
		type: 255; RSSI filter: 1 (-	T – search time	description in clause 6.3.2.1)
		60dBm)		
33	BLESENSOR X,Y	BLESENSOR:(0):	X – cell number of the	Binding sensors ADM31, ADM32 to the
		D8A05B9BEF5B, (1): , (2): ,	sensors list	tracker
		(3): , (4): ,	Y – sensor address	(detailed description in clause. 6.3.3 Adding
				sensors ADM31, ADM32 in a manual mode
				and viewing the list of added sensors)
34	BLESENSORINFO X	BLESENSORINFO:	X=04 -sensor number (from	Data request from bound sensors
		[0]:D8A05B9BEF5B; DT:1;	BLESENSOR sensors list )	ADM31/32
		PT:3; F:5; V:3.0; T:25.35;		(detailed description in clause. 6.3.3.1 Data
		L:412.80; H:35; R:-51;		receipt from bound sensors ADM31/32)
		LMT:6; S:0;		
35	TEMPRANGE X,A,B		X - sensor number from	Set acceptable range for temperature
			BLESENSOR list.	sensor.
			АиВ–range limits of	
			acceptable temperature.	
36	LIGHTRANGE X,A,B		X – sensor number from	Set acceptable range for illumination
			BLESENSOR list	sensor.
			A and B – range limits of	
			acceptable illumination.	

	Command	Answer	Parameters	Description
37	HUMIDRANGE X,A,B		X - sensor number from	Set acceptable range for humidity sensor.
			BLESENSOR list	
			A and B - range limits of	
			acceptable humidity.	
38	ANGLERANGE X,A,B,C,D		X - sensor number from	Set the range of lower and upper state of
			BLESENSOR list	the sensor
			A,B – lower and upper limits	
			for the "lower" sensor state.	
			C,D – lower and upper limits	
			for the "upper" sensor state.	
39	ALARMPERIOD X	ALARMPERIOD X	X – time in seconds	Set the period of information packets in an
				alarm mode.
40	BLEFUEL X,Y		X -cell number of the	Binding BLE fuel level sensor to the
			sensors list	tracker.
			Y – sensor address	(detailed description in clause 6.3.4 Adding
				BLE fuel level sensor in a manual mode and
				viewing the list of added sensors.)
41	BLEFUELINFO X		X - cell number of the	Data request from bound fuel level sensors
			BLEFUEL sensors list	(detailed description in clause 6.3.4.1 Data
				receiving from connected fuel level sensors
				)

	Command	Answer	Parameters	Description
42	BLEPROTOCOL X		X – figure detecting the set of	Set the data set to be transmitted from
			data to be transmitted	sensors ADM31/32. (detailed description in
				clause. 7.2 Selecting data to be transmitted
				to the server from sensors ADM31/32).
43	LIGHTPROTOCOL X		X=0 – shortened	Select the transmission format of the
			X=1 - full	illumination level (detailed description in
				clause 7.3 Selecting the transmission format
				of the illumination level )

## 9 Updating tracker software

The tracker software (firmware) can be updated via Bluetooth radio channel or a GPRS channel.

## 9.1 Updating tracker software via ADM Configurator

The ADM Configurator program, if the computer has access to the Internet, checks the current firmware version on the update server, and, if necessary, downloads the firmware file.

#### To update the firmware, do the following:

establish connection between the tracker and the ADM Configurator program using the procedure described in. <u>5.1 «Connection to ADM Configurator»;</u>

- if the firmware version is found to be more up-to-date than the one installed in the tracker, ADM Configurator will notify of its presence -a notification will be displayed in the lower left corner;
- 2) click "Update available";
- 3) in the opened "Notifications" tab, click "Update";
- 4) after the update, the tracker will reboot and become available for operation

**ATTENTION!** Do not switch off the tracker during the firmware upgrade until the tracker is detected by the setup program. Otherwise, it is possible to damage the software, which must be restored in the service center of the manufacturer.

## 9.2 Updating tracker software via ADM Configurator using a firmware file

#### The firmware file must be requested from the technical support.

To update the firmware via Bluetooth radio channel using the firmware file, do the following: establish connection between the tracker and the ADM Configurator program using the procedure described in. <u>5.1 «Connection to ADM Configurator»;</u>

- 1) open the "Settings" section in the "Device" tab, click "Flash file";
- 2) click «Update» in the pop-up window;
- 3) drag the firmware file to the appropriate field in the ADM Configurator window;
- 4) after updating the firmware, the tracker will reboot and become available for operation

**ATTENTION!** Do not switch off the tracker during the firmware upgrade until the tracker is detected by the setup program. Otherwise, it is possible to damage the software, which must be restored in the service center of the manufacturer

#### 9.3 Updating the tracker software via GPRS

To update the tracker software via GPRS, install the active SIM card in the tracker, enter the APN, user, pass of the cellular operator.

Otherwise, the tracker will be in the firmware download mode from the update server until all connection attempts are exhausted. The update process starts after the tracker receives the **"UPDATE"** command via one of the possible channels: Bluetooth, GPRS, SMS. After receiving the **"UPDATE"** command the tracker connects to the update server and downloads the current firmware. After a successful upgrade, the tracker switches to the basic mode of operation with the access point settings and server addresses that were installed before the update. The remaining settings after the update should be checked and, if necessary, reinstalled. Depending on the status of the GSM network, the upgrade process takes an average of 2 to 10 minutes. If there is no possibility to download the update, the tracker will return to operation with the available software.

## **10 Handling and transportation regulations**

Trackers should be stored in a warehouse at a temperature of +5°C to +40°C and relative humidity at most 85 %.

After tracker transportation in sub-zero temperatures they should be stored at room temperature within 24 hours.

# **11 Warranty obligations**

The manufacturer guarantees the tracker proper function within 12 months from the day of its sale if consumer meets all the requirements and follows all the rules of transportation, storage, installation and handling.

The warranty does not cover:

- a tracker with mechanical damages and defects (cracks and chips, dents, signs of impacts, etc.) caused by consumer as a result of handling, storage and transportation rules violation.
  When there are signs of oxidation or other proofs of liquid penetration in the device housing;
- a tracker without housing;
- a tracker with signs of repair performed beyond the manufacturer's service center;

- a tracker with signs of electrical and/or other damages caused as a result of unacceptable changes in external power network parameters or improper use of the tracker;
- a tracker disabled because of an unauthorized software upgrade.

The device software is licensed, terms related to the manufacturer's limited liability in the framework of the License Agreement are provided at the web <a href="https://neomatica.com/upload/docs/license\_en.pdf">https://neomatica.com/upload/docs/license\_en.pdf</a>

# 12 Marking and packaging

Marking is placed on the tracker housing. The tracker is packed in an individual box, which protect them during transportation and storage. Multipack is possible.

# 13 Disposal

Device recycling is performed according to national and local norms and requirements.

# 14 Scope of supply

Table 6. Scope of supply

Device name	Quantity	Serial number	Comments
Tracker ADM333BLE			
MF3-8F connector to connect			
power and sensors with cables			
Datasheet			

# **15 Acceptance certificate**

Trackers ADM333BLE GLONASS/GPS-GSM/GPRS SHAIF.464512.001-11 in quantity of \_\_\_\_\_ pcs. correspond to SHAIF.464512.001 TV and are valid for use.

Manufacture date:



Manufacturer: «Neomatica» LLC 24a Malkova Str., office 6, 614087, Perm, Russia Tel: +7 (342) 2-111-500. E-mail: <u>sale@neomatica.ru</u>

# Appendix A. Description of the bits of the field «STATUS»

Bits	Field description «Status»	Mask value
0	Sign of tracker restart	1
1	Number of active SIM card (0 – SIM0, 1 – SIM1)	2
2	No connection with server	4
3	-	8
4	Sign of low voltage of the battery	16
5	Sign of invalidity of coordinates (validity)	32
6	Coordinates are fixed at the absence of movement	64
7	External power supply of the tracker is switched off	128
8	-	256
9	Sign of GNSS jamming	512
10	GNSS jamming	1024
11	-	2048
12	-	4096
13	-	8192
14	Time is synchronized according to GSM	16384
15	-	32768

Table A.1. Description of the field bits «Status»

# Appendix B. Description of transmitted parameters in Wialon

Parameter	Description
acc	Current point acceleration module, km/h/s
sats_glonass	Number of GLONASS satellites involved in fixing a navigation problem
sats_gps	Number of GPS satellites involved in fixing a navigation problem
hdop	Precision reduction on a horizontal plane
pwr_ext	External power voltage value, mV
pwr_int	Voltage in built-in battery, мВ
adc1	Analogue input voltage value, A_IN0, мВ
adc2	Analogue input voltage value, A_IN0, мВ
adc3	GSM signal level, %
adc4	
adc5	
adc6	
fuel1	Fuel level value in sensor №0
fuel2	Fuel level value in sensor №1
fuel3	Fuel level value in sensor №2
temp1	Temperature value in sensor №0
temp2	Temperature value in sensor №1
temp3	Temperature value in sensor №2
I/O	Value of device status
vib	
in1	Discrete state on input AIN0
in2	Discrete state on input AIN1
in3	
in4	
in5	
in6	
in7	
in8	
in9	Sign of tracker restart
in10	Number of active SIM card (0 – SIM0, 1 – SIM1)
in11	No connection with server
in12	
in13	Sign of low battery voltage

Table B.1. Description of transmitted parameters in Wialon system

in14	Sign of invalidity of coordinates
in15	Coordinates are fixed in the absence of movement
in16	External power supply of the tracker is switched off
in17	
in18	Suspicion of GNSS jamming
in19	GNSS is revealed
in20	
in21	
in22	
in23	Time is synchronized according to GSM
in24	
Can1-Can25	Fields are used to transmit data from BLE sensors. Fields description
Can26	Battery voltage, BLE fuel level sensor 0
Can27	Battery voltage, BLE fuel level sensor 1
Can28	Battery voltage, BLE fuel level sensor 2